



Popcorn Machine

Operational Tips:

SWITCHES

Light and Warmer Switch—turns on heat lamp and optional strip heater under corn pan

Kettle Motor Switch—turns on motor that drives kettle agitator shaft

Kettle Heat Switch—turns on heat element inside kettle

Note: DO NOT COVER air vent holes. Motor air intake and exhaust holes at top of the machine MUST be clear of any obstruction.

AVOID SERIOUS BURNS! Do not touch kettle while it is hot.

To Pop:

1. Turn on kettle heat switch and kettle motor and exhaust switch.
2. "Test pop" a kettle of corn: place oil measure in kettle with three corn kernels; when kernels pop, place remainder of oil, measured corn and flavouring in kettle; close lid.
3. When corn has popped, rotate handle to empty popcorn from kettle; return kettle to upright position.
4. Repeat the cycle; subsequent batches are always more flavourful than the initial batch.
5. Turn off the kettle heat switch on the final batch when the popcorn breaks over the lid of the kettle to eliminate smoke and odour.
6. Turn off kettle heat and kettle motor and exhaust switches.
7. Wipe exterior of kettle with heavy cloth after cooling of kettle to prevent burn or stain of oil drippings.
8. Turn off all switches.

To Clean:

1. Allow kettle to cool until warm enough to handle.
2. Unplug kettle and remove from machine.
3. Wipe kettle, kettle lids, crossbar and exterior clean. DO NOT IMMERSE KETTLE IN WATER.
4. Remove popped corn and pack in bags.
5. Remove the "old maid" pan, empty unpopped kernels and wipe clean.
6. Wipe interior of machine clean.
7. Return the machine clean to the Party Centre to avoid cleaning charges.

We pride ourselves on the quality of our rental equipment and the cleanliness of it when it leaves the store. If for some reason you are not satisfied when you receive the machine, please call us

Tim's Party Centre 905-623-9838 timspartycentre@rogers.com